


INSTRUCTION MANUAL
FOR
MODEL 58C
IMPULSE NOISE COUNTER



NORTHEAST ELECTRONICS CORPORATION

P.O. BOX 649 - CONCORD, N.H. 03301

(603) 224-7466



INSTRUCTION MANUAL
FOR
MODEL 58C
IMPULSE NOISE COUNTER

ISSUE 1



NORTHEAST ELECTRONICS CORPORATION

P. O. BOX 649 — CONCORD, N. H. 03301

PROPRIETARY NOTICE

The information contained in this publication is the property of Northeast Electronics Corporation and may not be reproduced or used for manufacturing purposes or disclosed to third parties without the written permission of Northeast Electronics Corporation.

WARRANTY

NEC warrants all products manufactured or sold by NEC to be free from defects in materials and workmanship, subject to the following terms and provisions.

NEC's obligations under this warranty are limited to repairing, adjusting, or replacing at our option, with reasonable promptness, any NEC product which shall within twelve (12) months after delivery to the original purchaser, and after normal and proper usage, prove to be defective on NEC inspection, provided that the purchaser shall have reasonably inspected products when received and notified NEC of any apparent defects discovered within fifteen (15) days of receipt of shipment. NEC shall not be liable for any manufacturing costs of the buyer, lost profits or good will of the buyer, or any other special or consequential damages sustained or expenses incurred by the buyer by reason of the use or sale of any defective NEC product.

No products may be returned to NEC except with our written permission. After receiving NEC factory authorization, material requiring repair or replacement should be sent prepaid to the factory accompanied by a written statement setting forth as completely as possible the defects and the conditions under which they occurred. Material delivered by NEC shall not be considered defective if it satisfactorily fulfills the buyer's performance requirements and/or is in accordance with approved samples. NEC's obligations on performance of products delivered shall be limited to complying with specifications accompanying a purchase order or with published specifications on standard catalog items. This warranty does not extend to any NEC products which have been subject to misuse, neglect, accidents or improper installation or applications, nor shall it extend to units which have been repaired or substantially altered outside the NEC factory, nor to any associated instruments, equipments or apparatus. This warranty is in lieu of all other warranties, express or implied.

TABLE OF CONTENTS

Section	Title	Page
1	GENERAL DESCRIPTION	1-1
2	SPECIFICATIONS	2-1
3	OPERATING INSTRUCTIONS	3-1
4	CIRCUIT DESCRIPTION	4-1
5	MAINTENANCE AND CALIBRATION	5-1
6	ELECTRONIC PARTS LIST	6-1
7	SCHEMATIC DIAGRAMS	7-1




Figure 1-1. Model 58C Impulse Noise Counter

SECTION 1

GENERAL DESCRIPTION

1.1 General Description: The Model 58C is an Impulse Noise Counter and Circuit Noise Measuring Set utilizing a mechanical readout for recording impulse hits at threshold levels from 20 dBrn to 99 dBrn in 1 dB increments. A slide switch allows for selection of either a 7 or 10 pulse per second count rate. A built-in timer provides for observation periods of up to one hour. An output monitor jack allows the operator to monitor or record the signal being measured.

1.2 The set will measure the value of metallic noise from 20 to 99 dBrn, weighted or flat, and longitudinal Noise-To-Ground from 60 to 139 dBrn.

1.3 Three internal weighting networks, C-MSG, FLAT, and 10.2-51 kHz are provided. Connections for external weighting are also available on the front panel with flat response to >100kHz.

1.4 Input Impedance of 135,600 and 900 Ω , bridging or terminated are provided, plus dial through capability with holding circuit.

1.5 The unit operates from internal batteries with a battery life of 200 hours or from -48 VDC CO Battery Source. It weighs 11 $\frac{1}{2}$ pounds and measures 9" w x 7" h x 8 $\frac{1}{2}$ " d.



Digitized by the Internet Archive
in 2025

https://archive.org/details/manualsplus_11091

SECTION 2

SPECIFICATIONS

SENSITIVITY

Metallic: Impulse Noise and Circuit Noise;
20 to 99 dBrn
Longitudinal Noise-To-Ground: 60 to
139 dBrn.

INPUT IMPEDANCES

Balanced Input Transformer.
a. Terminated 135,600 or 900 Ω .
b. Bridging loss less than 0.25 dB @ 1 kHz.

FREQUENCY RESPONSE

Wide band (EXT) -3 dB; <50 Hz >100 kHz.
10.2-51 kHz, C-MSG, FLAT.

COUNTING RATE

7pps or 10 pps selectable by front panel
switch

HOLD CIRCUIT

Hold Coil: DC Resistance
500 Ω $\pm$ 20%

POWER REQUIREMENTS

a. Battery Operation:
12"D" cell batteries
Current Drain: approximately 100 mA
peak, 60 mA average
b. 48 volt operation.

SIZE:

9" w x 7" h x 8 $\frac{1}{2}$ " d.

WEIGHT:

11 $\frac{1}{2}$ pounds.




Figure 3-1. Front Panel Controls

SECTION 3

OPERATING INSTRUCTIONS

3.1 FRONT PANEL CONTROLS

NAME OF CONTROL	FUNCTION
1. COUNTER RESET (mechanical)	Resets mechanical counter to all zeros.
2. DBRN (Thumbwheel Controls)	Attenuator, 10 dB and 1 dB steps, for setting the threshold sensitivity for either impulse or circuit noise measurements.
3. IMPEDANCE (Push Buttons)	Provides for selection of the following: Noise-To-Ground. Measurements Bridging or Terminate Hold Circuit 135, 600 or 900 Ω impedance
4. WEIGHTING (Push Buttons)	Selects C-MSG, FLAT, 10.2-51 kHz or EXT weighting.
5. COUNT RATE	Selects either a 7 or 10 pps count rate.
6. FUNCTION	Allows for selection of counting Impulse noise or measuring the average value of Metallic Noise.
7. TIME-MINUTES (POWER)	60 minute timer with a countiuous operating position. Timer applies power to the set when activated.
8. BATT TEST (Push Button)	Indicates battery condition. (Timer must be activated).
9. MEAS (Turn Button Switch)	Provides for connecting line circuit to dial jack.

Section 3

3.2 OPERATION: Turn TIME-MINUTES Control counter-clockwise to continuous position. Depress BATT TEST push button. TEST OK light should illuminate.

3.3 Connect the external line to be tested to the LINE jack or to the T-R-S binding posts. A type 310 or a twin banana plug can be used to establish connection to the Model 58C input circuit.

3.4 If the line connection is to be dialed:

- a. Connect a dial or telephone to the DIAL jack using a 310 type plug.
- b. Place MEAS turnbutton switch in the horizontal position. This transfers all line jacks to the DIAL jack.
- c. Select desired impedance function, i. e. 900Ω , TERM, HOLD.
- d. Dial the desired number.
- e. When line connection has been established, place MEAS turnbutton switch in the vertical position.
- f. The dial may now be removed. The internal hold circuit will maintain the connection.

3.5 Select the desired weighting characteristic. If an external weighting network is to be used, remove shorting link between IN and OUT binding posts and make the appropriate filter connections to these binding posts. External weighting networks to be used should be for 600Ω impedance and any insertion loss added to the sensitivity setting of the Model 58C. Other networks with other impedances may be used and the change in gain added to or subtracted from the sensitivity setting.

3.6 TO MEASURE CIRCUIT NOISE. Slide FUNCTION switch to the MEAS NOISE position. DO NOT attempt to measure circuit noise during an impulse noise test.

3.7 a. If the NOISE lamp is on: operate the DBRN control to decrease sensitivity until the MEAS NOISE lamp blinks or is on the threshold of turning off.

b. If the MEAS NOISE lamp is off: Operate the DBRN control to increase sensitivity until the MEAS lamp blinks or turns on.

NOTE

For either of the above cases, the corresponding sensitivity setting is the average value of the circuit noise.

3.8 TO MEASURE NOISE TO GROUND. Connect line to be tested to the LINE jack or T-R-S binding posts. Depress the N-GRD pushbutton.

3.9 Proceed as in 3.6 and 3.7 above. Add 40 dB to the dB_{rn} control setting.

3.10 TO MEASURE IMPULSE NOISE. Slide FUNCTION switch to MEAS IMPULSE position. Set sensitivity by operating DBRN control to the desired threshold level

3.11 Set desired count rate, 7 or 10 pps.

3.12 If test is to be timed, rotate the TIME-MINUTES control clockwise past 10 and set to desired time.

3.13 Immediately and momentarily depress the counter reset. This resets the counter to zero and establishes the start of the impulse noise test.

CAUTION:

From the start and during the course of an impulse noise test, DO NOT readjust or activate any controls.

3.14 At the end of test when timer has returned to zero, record the reading on the mechanical counter.

3.15 TO MONITOR. Plug headset in the MONITOR jack which accepts a 310 type plug. Output level is approximately -24 dBm in 600Ω . Monitor response is determined by the weighting networks selected. Signal is tip, ring and sleeve are ground.

SECTION 4

CIRCUIT DESCRIPTION

4.1 INPUT CIRCUIT LINE SECTION (See Figure 7-1)

- a. The balanced input circuit provides a choice of connectors for establishing connection to the line. Turn button switch S5 connects all line jacks to the dial jack for dialing purposes.
- b. The hold circuit consisting of inductor L1 is placed across the line by depressing push button S103.
- c. The terminations are selected by push buttons S104, S105, and S106 and consist of resistors R101, R102 and R103. The terminating resistor selected appears across the line via the terminate switch S102.
- d. DC blocking up to 150V is provided by capacitors C119 and C120 in series with the balanced line input.
- e. Transformer T1 presents a balanced input to the line. Impedance switches select the proper transformer circuit connections for impedance level equalization.
- f. N-GRD. Measurements are made by depressing pushbutton S101. The Terminations and Transformer T1 are removed from the circuit in this mode. A 40 dB balanced loss pad, consisting of R132 through R135, is inserted in the line after the dc blocking capacitors.

4.2 INPUT AMPLIFIER (See Figure 7-1)

- a. The input amplifier has a gain of approximately 44 dB determined by the ratio of resistors R107, R108 and R109. The input attenuator, located on deck 3 of switch S1, has 0 dB of loss in the 20 through 50 dB position and 40 dB loss in the 60 through 90 dB position. Following the input amplifier is a second attenuator, located on deck 2 of switch S1, providing the proper source impedance for the weighting networks in addition to losses of 0, 10, 20 and 30 dB.

4.3 WEIGHTING NETWORKS (See Figure 7-1)

- a. The impedance for the filters is 600 Ω for both source and load. The source

impedance is provided by the second attenuator and the load impedance is provided by the third attenuator located on deck 1 of switch S1.

- b. The C-MSG weighting characteristics are determined by the passive elements of the filter with an insertion loss of approximately 9.5 dB.

- c. In the flat weighting network, capacitor C107 limits the high frequency response with a 6 dB per octave roll-off. Resistors R121, R122 and R123 provide impedance matching and level equalization with an adjusted loss of approximately 9.5 dB.

- d. The 10.2-51 kHz band pass filter network is a cascaded High Pass-Loss Pass filter with approximately 18 dB per octave slopes. Resistors R124, R125 and R126 provide impedance matching and level equalization with an adjusted loss of approximately 9.5 dB.

- e. In the EXTERNAL WTG. position, connections are brought out to a pair of binding posts on the front panel. Resistors R118, R119 and R120 provide impedance matching and level equalization with an adjusted loss of approximately 9.5 dB.

- f. The third attenuator, located on deck 1 of S1, provides the proper terminating impedance for the weighting networks in addition to 9 dB of attenuation in 1 dB steps

4.4 IMPULSE PEAK DETECTOR (See figure 7-2) The impulse peak detector consists of an amplifier, U201, driving a DC biased diode bridge, U203. The bridge holds a DC amplifier, U202, in an off condition. The sensitivity of amplifier U201 is approximately -41.5 dB and is determined by the ratio of resistors R204, R205 and R207. Variable resistor R211, located in series with the bridge bias circuit, provides a means for adjusting the bias to give equal triggering on both polarities of the input signal.

4.5 The DC amplifier, U202, is biased in a normally off condition. When the input signal peak exceeds the sensitivity setting, the bias condition is overcome and the amplifier output switches thereby generating a rectangular pulse.

4.6 COUNTRATE TIMER (See figure 7-2) U301, Q301 and Q302 constitute the Blanking Interval Circuitry which gates the counter for the selected countrate.

4.7 The circuit is activated by an impulse hit which drives pin 10, U202, to 0 volts. This voltage is coupled to pin 4, U301, and causes pin 2, U301, to switch from low to high, thus placing a positive charge on the timing capacitor C301. The capacitor discharges through the base of Q302. The levels at pins 4 and 5 keep U301 from changing state until the capacitor is sufficiently discharged. At that time, Q302 releases, U301 changes stage and the capacitor charges through Q301. When Q301 releases, the cycle is ready to repeat. The mechanical Impulse Counter is driven by Q304 which is gated by the countrate timing circuit.

4.8 CIRCUIT NOISE DETECTOR (See figure 7-2) The circuit noise detector consists of a DC amplifier, U204, which averages the signal

being measured. When the instrument sensitivity is adjusted such that the circuit noise measured is sufficient to trigger U204, Q205 is turned on and the NOISE LAMP, DS2, illuminates.

4.9 POWER SUPPLY REGULATORS (See figure 7-2). The -10V regulator is a series pass configuration with zener reference. Regulator supply is either internal battery, or -48 VDC supplied via a panel jack which accepts a 310 type plug. The -5V regulator is also a series pass configuration utilizing a voltage divider for reference. Supply for the -5V regulator is from the -10V buss.

4.10 BATTERY TEST CIRCUIT: Depressing the battery test switch, S4, will illuminate the TEST OK lamp, DS1 as long as battery voltage is sufficient to fire the -10V reference zener. The lamp will not illuminate when battery voltage falls below the required level.




Figure 4-1. Model 58C Block Diagram

SECTION 5

MAINTENANCE AND CALIBRATION

5.1 MAINTENANCE. The overall schematic diagram identifies all components within the instrument. TEST POINT WAVEFORMS, VOLTAGES, and LEVELS also appear on the diagram.

5.2 TROUBLESHOOTING. In the event of a malfunction, ensure that:

- a. The batteries test good or, if on -48V operation, that the dc power cord has proper polarization and is properly connected.
- b. All external line plugs are properly wired and inserted in the correct jacks.
- c. All controls are set in accordance with the operation section of this manual.
- d. The test being performed is within the specification limits of the instrument.

NOTE

When it has been determined that a malfunction does exist, an attempt at interpreting the symptoms should be made before removing the set from the case. See table 5-1.

5.3 To remove the set from the case, proceed as follows:

- a. Switch off power to the set.
- b. Loosen four captive screws indicated by arrow heads on front panel.
- c. Carefully withdraw set from the case, and if desired, disconnect power cord from the battery compartment.
- d. Reconnect power cord when necessary and switch power on when needed.

TABLE 5-1

SYMPTOM	PROBABLE CAUSE
Set is inoperative in both impulse and circuit noise mode but not in impulse mode.	First or second amplifier not functioning. Check U101, U201.
Set functions in circuit noise mode but not in impulse mode.	DC amplifier, U202 countrate timer, or counter driver circuitry not functioning. Check U202, U301, Q301-Q304.
Set functions in impulse mode but not in circuit noise. Noise lamp not functioning.	DC amplifier, U204; lamp driver or lamp not functioning. Check U204, Q205 and DS-2.
Intermittent or abnormal counter operation.	Battery voltage at or below required operating level. Check batteries.

5.4 TEST EQUIPMENT REQUIRED

TABLE 5-2

EQUIPMENT		USE
VOM: NEC Model 2000, Triplett Model 680-NA, or equivalent.		To measure dc volts
VTVM: NEC Model 2000, TTS 4C or Hewlett-Packard 400 series		To measure dBm and/or low level ac volts
OSCILLOSCOPE: Any suitable model oscilloscope.		To observe waveforms
OSCILLATOR: NEC TTS 4C, TTS 43A or equivalent.		Calibrated signal source

5.5 CALIBRATION. The Model 58C has been calibrated at the factory before shipment. Re-calibration should only be performed if component parts are replaced because of a malfunction. Only the circuit directly involved with the component replacement need be re-calibrated.		5.8	a. If the error still exists and/or the second amplifier, U201, was changed proceed to Impulse Noise Calibration, paragraph 5.9.
5.6 CIRCUIT NOISE CALIBRATION CHECK.			b. If the error still exists but only in the FLAT, 10.2-51 kHz, or EXT. weighting, proceed as follows:
a. Set up Model 58C Front Panel Controls as follows:			1. Measure and record the signal level at pc 1.5 while in C-MSG weighting.
PUSHBUTTONS	TERM, 600 Ω , C-MSG		2. Switch to weighting position in which error occurred.
DBRN (Thumbwheels)	50		3. If in FLAT position, adjust R123 for signal level recorded in step (1).
FUNCTION	MEAS. NOISE		4. If in EXTERNAL position, adjust R120 for signal level recorded in Step (1)
POWER	CONTINUOUS		5. If in 10.2-51 kHz position, change signal frequency to 25 kHz and adjust R126 for signal level recorded in step (1)
b. Connect a 1 kHz signal with a level of -40 dBm from a 600 Ω source to the line input of the Model 58C. The MEAS. NOISE lamp should be on the threshold of lighting ± 0.3 dB.			
5.7 CIRCUIT NOISE CALIBRATION. If it is found necessary to recalibrate, first determine in what section the error exists.		5.9	IMPULSE NOISE CALIBRATION CHECK.
a. With conditions outlined as in 5.6 (a) above, decrease input level to -50 dBm and set the DBRN CONTROL to 40 dBm.			a. Set up Model 58C Front Panel Controls as follows:
b. Refer to the overall schematic diagram and use indicated levels for reference.			PUSHBUTTONS TERM 600 C-MSG
c. If the error is found to exist at the output of the first amplifier, U101 then the amplifier gain control, R108 needs adjustment.			IMPULSE LEVEL, DBRN 40
			FUNCTION MEAS. IMPULSE
			COUNTRATE 7 PPS
			POWER CONTINUOUS

b. Connect a 1 kHz signal with a level of -53 dBm from a 600 Ω source to the Line Input of the Model 58C.

c. Adjust Input Level for periodic count accumulation at threshold. Resulting Input Level should be within ± 0.5 dB of -53 dBm.

d. If an error exists, perform steps 5.7 and 5.8 before continuing.

5.10 Impulse Noise Calibration. If the average noise calibration has been carried out and an error still exists, or if the second amplifier, U201 has been changed and recalibration is necessary, proceed as follows:

a. Set up Model 58C Front Panel Controls as in paragraph 5.9 (a). Connect a 1 kHz signal with a level of -53 dBm from a 600 Ω source to the line input of the Model 58C.

b. If U201 was not changed, adjust R205 for periodic count accumulation at threshold. Only a slight adjustment should be necessary.

5.11 If U201 was changed, the BALANCE Control, R211, may require readjustment to insure equal sensitivity to both polarities of the input signal. Proceed as follows:

a. Connect Oscilloscope to TP2.3 located on PC2. Adjust oscilloscope for positive internal triggering with horizontal time base set for 0.1 ms/cm and vertical sensitivity of 5V/cm.

b. Increase input signal level to -52.5 dBm and adjust oscilloscope for correct horizontal triggering.

c. Observe waveform and adjust balance control, R211 for a recurring rectangular pulse every 0.5 ms. This indicates that the impulse detector is triggering on both polarities of the input signal.

d. Decrease input level to -53 dBm and adjust amplifier gain control, R205 for periodic count accumulation.

e. At this threshold level, triggering on only one polarity will be observed. Increasing input level by 0.2 or 0.3 dB should result in a pulse every 0.5 ms. Correct adjustment of the balance control is indicated when triggering of both polarities of the input signal occurs within 0.5 dB of threshold.

5.12 COUNTRATE TIMER CALIBRATION CHECK

a. Set up Model 58C Front Panel Controls as in paragraph 5.9 (a). If possible, power the 58C from -48V or use fresh batteries.

b. Connect a 1 kHz signal with a level of -50 dBm from a 600 Ω source to the line input of the Model 58C. Instrument should be counting.

c. Connect an oscilloscope to the positive end of C301. Adjust the oscilloscope for positive internal triggering with horizontal time base set for 20ms/cm and vertical sensitivity of 5V/cm.

d. Adjust scope for proper horizontal triggering.

e. The time for one complete cycle of the waveform should be 143ms. If recalibration is necessary, adjust R306 for the correct time period.

f. Change countrate to 10 pps. Adjust oscilloscope horizontal time base for 10ms/cm.

g. The time for one complete cycle should be 100ms. If recalibration is needed, adjust R304 for the correct time period.

ELECTRONIC PARTS LIST

6.1 INTRODUCTION.

6.2 The following pages contain the parts list for the Model 58C Impulse Noise Counter.

6.3 FSCM CODE NUMBERS.

6.4 This is the Federal Supply Code of Manufacturers as issued October 1969. A list of codes and their respective manufacturers is given below.

LIST OF MANUFACTURERS

Code No.	Manufacturer
00303	Shelly Associates Inc. Segundo, Calif. 90245
01121	Allen Bradley Milwaukee, Wis. 53204
01295	Texas Instrument Inc. Dallas, Texas 75231
05397	Union Carbide "Kemet" Div. N.Y., N. Y. 10017
06486	IRC Division of TRW Lynn, Mass. 01905
08538	Chicago Dynamic Ind. Chicago, Ill. 60614
09353	C&K Components Inc. Newton, Mass. 02158
12065	Transitron Electric Corp. Boston, Mass. 02128
15801	Fenwal Electronic Inc. Framingham, Mass. 01701
15873	Motorola Inc. Arcade, N.J. 14009
18324	Signetics Corp. Sunnyvale, Calif. 94086
22650	Whale Electronics Nashville, Tenn.
49671	RCA Corp. N.Y., N. Y. 10020
71450	CTS Corp. Elkhart, Ind. 46514
71590	Centralab Milwaukee, Wis. 53201
75523	Sodeco N.Y., N. Y. 10036
79919	Rhodes M H Inc. Hartford, Conn. 06101
81073	Grayhill Inc. La Grange, Ill. 60525
81095	Triad Transformer Corp. Venice, Calif. 90293
82389	Switchcraft Inc. Chicago, Ill. 60630
83330	Herman H. Smith Inc. Brooklyn, N.Y. 11207
86632	Newton Engineering Newton, Mass. 02161
99800	Delevan Electronics Corp. Auroa, N.Y. 14052

PC Board E95600

Amplifier and Filter Board

Ref Desig.	Description	Manufacturer (FSCM Code No.)	Part Number
R101	R: 137 Ω , $\pm 1\%$, $\frac{1}{2}W$	06486	CECTO
R102	R: 634 Ω , $\pm 1\%$, $\frac{1}{2}W$	06486	CECTO
R103	R: 953 Ω , $\pm 1\%$, $\frac{1}{2}W$	06486	CECTO
R104	R: 82K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R105	R: 180K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R106	R: 270K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R107	R: 536 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R108	Potentiometer 200	71450	UPE200RE1
R109	R: 100K, $\pm 1\%$, $1/8W$	06486	CEATO
R110	R: 1500 Ω , $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R111	R: 600 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R112	R: 1910 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R113	R: 887 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R114	R: 6040 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R115	R: 665 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R116	R: 18.7K, $\pm 1\%$, $1/8W$	06486	CEATO
R117	R: 600 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R118	R: 383 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R119	R: 237 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R120	Potentiometer 200	71450	UPE200RE1
R121	R: 383 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R122	R: 237 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R123	Potentiometer 200	71450	UPE200RE1
R124	R: 383 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R125	R: 237 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R126	Potentiometer 200	71450	UPE200RE1
R127	R: 681 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R128	R: 619 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R129	R: 85 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R130	R: 1800 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R131	R: 183.7 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R132 and R133	R: 39.2K, $\pm 1\%$, $1/8W$	06486	CEATO
R134	R: 80.6K, $\pm 1\%$, $1/8W$	06486	CEATO
R135	R: 1.0K, $\pm 1\%$, $1/8W$	06486	CEATO
C101	C: 0.22 μF , @50V	05397	KR22W50K
C102	C: 20 μF , @15V	13606	TE-1157
C103	C: 8.2 μF , @15V	05397	K8R2W15K
C104	C: 100pF, @1kV	71590	DD-101
C105	C: variable 5-25pF	72982	557-091COPO-39R
C106	C: 20 μF , @15V	13606	TE-1157
C107	C: 0.039 μF , @100V	13606	225P
C108 and C109	C: 0.03 μF , @100V	13606	225PW
C110 and C111	C: 0.006 μF , @100V	13606	225PW
C112	C: 1 μF , @35V	05397	K1W35K
C113 and C114	C: 0.2 μF , @75V	13606	225P
C115	C: 0.15 μF , @75V	13606	225PZ
C116	C: 0.25 μF , @75V	13606	225PZ
C117	C: 0.2 μF , @75V	13606	225P
C118	C: 0.47 μF , @25V	13606	5C11
C119 and C120	C: 100 μF , @150VDC	13606	39D107F150FP4
L101	Inductor 7500 μH	99800	2500-70
L102	Inductor 2700 μH	99800	2500-48
L103	Inductor 150mH	81095	EA-150
L104 and L105	Inductor 30mH	81095	EA-030
U101	Integrated circuit	01295	SN72709
S101 thru S110	Pushbutton switch 1	71590	2KBM064000




Figure 6-1. Component Location E95600

PC Board E95613

Gating and Driver Board

Ref Desig.	Description	Manufacturer (FSCM Code No.)	Part Number
R301	R: 12K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R302 and R303	Selected value		
R304	Potentiometer 1K	71450	UPE200RE1
R305	not used		
R306	Potentiometer 2K	71450	UPE200RE1
R307	not used		
R308	R: 33K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R309	R: 1K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R310	R: 100, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R311	R: 1K, $\pm 1\%$, $1/8W$	06486	CEATO
R312	R: 10 Ω , $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R313	R: 57 Ω , $\pm 10\%$, $\frac{1}{2}W$	01121	CB
C301	C: 50 μF , 15V	13606	TE-1160
CR301	Diode	15873	1N198
CR302	Diode	12065	1N4003
RT301	Thermistor 1K, $\pm 10\%$	15801	KA31L1
Q301 and Q302	Transistor NPN,	15873	2N3903
Q303	Transistor PNP	15873	2N3905
Q304	Transistor NPN	49671	2N2102
U301	Integrated circuit	18324	SP-380A




Figure 6-2. Component Location E95613

PC Board E95614

Detector and Regulator Board

Ref Desig.	Description	Manufacturer (FSCM Code No.)	Part Number
R201	R: 22K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R202	R: 100K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R203	R: 120K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R204	R: 1K, $\pm 1\%$, $1/8W$	06486	CEATO
R205	Potentiometer 1K	71450	UPE200RE1
R206	R: 1500 Ω , $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R207	R: 68.1K, $\pm 1\%$, $1/8W$	06486	CEATO
R208	R: 8.2K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R209	not used		
R210	R: 6.8K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R211	Potentiometer 5K	71450	UPE200RE1
R212	R: 560 Ω , $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R213 and R214	R: 1K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R215	R: 560K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R216	R: 10K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R217	R: 560K, $\pm 10\%$, $\frac{1}{2}W$	01121	CB
R218	R: 100K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R219	R: 1500 Ω , $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R220 and R221	R: 10K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R222	R: 1500 Ω , $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R223	R: 10K, $\pm 10\%$, $\frac{1}{4}W$	01121	CB
R224	R: 6.04K, $\pm 1\%$, $1/8W$	06486	CEATO
R225	R: 665 Ω , $\pm 1\%$, $1/8W$	06486	CEATO
R226	Potentiometer 1K	71450	UPE200RE1
R227	R: 2200 Ω , $\pm 10\%$, $\frac{1}{4}W$	01121	CB
C201	C: 100 μF , @15V	13606	TE-1162
C202	C: 0.18 μF , @75V	13606	225PZ
C203	C: 22 μF , @6V	05397	K22W6K
C204	C: 100pF, @1kV	71590	DD-101
C205	C: 3.3pF, @1kV	71590	DD-3R3
C206	C: 50 μF , @15V	13606	TE-1160
C207	C: 20 μF , @15V	13606	TE-1157
C208	C: 1000 μF , @12V	05844	9-85PSD
C209	C: 1 μF , @25V	13606	5C13
C210	C: 200 μF , @20V	22650	12-65PSS200-205
C211 thru C213	C: 0.47 μF , @25V	13606	5C11
C214	C: 5 μF , @15V	13606	TE-1152
C215	C: 0.005 μF , @50V	71590	CK-502
C216	C: 200pF, @1kV	71590	DD-201
CR201 and CR202	Diodes	01295	1N4148
CR203	Diode, zener 10.0V, $\pm 5\%$	15873	1N961B
Q201	Transistor, NPN	49671	2N3053
Q202	Transistor, PNP	01295	2N1375
Q203	Transistor, PNP	15873	MPS6519
Q204	Transistor, PNP	49671	2N4036
Q205	Transistor, PNP	15873	2N3905
U201 and U202	Integrated circuit	01295	SN72709
U203	Integrated circuit	49671	CA-3019
U204	Integrated circuit	01295	SN72709




Figure 6-3. Component Location E95614






Main Assembly

Ref Desig.	Description	Manufacturer (FSCM Code No.)	Part Number
R1 and R1A	R: 400 , 10W	13606	247E4015
R2	R: 64.9Ω, $\pm 1\%$, 1/8W	06486	CEATO
R3	R: 57.6Ω, $\pm 1\%$, 1/8W	06486	CEATO
R4	R: 52.3Ω, $\pm 1\%$, 1/8W	06486	CEATO
R5	R: 46.4Ω, $\pm 1\%$, 1/8W	06486	CEATO
R6	R: 41.2Ω, $\pm 1\%$, 1/8W	06486	CEATO
R7	R: 36.5Ω, $\pm 1\%$, 1/8W	06486	CEATO
R8	R: 31.6Ω, $\pm 1\%$, 1/8W	06486	CEATO
R9	R: 28.7Ω, $\pm 1\%$, 1/8W	06486	CEATO
R10	R: 26.1Ω, $\pm 1\%$, 1/8W	06486	CEATO
R11	R: 499Ω, $\pm 1\%$, 1/8W	06486	CEATO
R12	R: 49.9K, $\pm 1\%$, 1/8W	06486	CEATO
R13	R: 215Ω, $\pm 1\%$, 1/8W	06486	CEATO
CR1	Diode	12065	1N4003
CR2	Diode, zener	15873	1N1607
J1 and J2	Binding post	81073	29-1R
J3	Binding post	81073	29-1B
J4	Jack	82389	L12-B
J5	Binding post	83330	137-SP
J6	Jack	82389	L-12B
J7	Jack	82389	JJ-104
J8 and J9	Binding post	81073	29-1R
J10	Jack	82389	12-B
J11	Binding post	83330	137-SP
S1	Thumbwheel switch	08538	
S2	Timer switch	79919	71002J
S3	Slide switch	82389	46206L
S4	Pushbutton switch	82389	903
S5	Turnbutton switch	82389	9S-1175
S6	Slide switch	82389	46206L
T1	Input Xfmr	86632	NES-4640
L1	Hold coil	86632	TN-1274
M	Electrical inpulse counter	75523	TCEZ4E
DS1	Indicator light	00303	BEPH-74-G-L-L
DS2	Indicator light	00303	BEPH-74-W-L-L

SECTION 7

SCHEMATIC DIAGRAMS

7.1 INTRODUCTION. The following pages contain the schematic diagrams for the Model 58C.





INPUT LEVEL (dBm)

600Ω
-70
-60
-50
-40
-30
-20
-10
-0

S-I SETTING

dBm	LEVEL (dBm)
20	-70
30	-60
40	-50
50	-40
60	-30
70	-20
80	-10
90	-0



- NOTES:
1. UNLESS OTHERWISE INDICATED: CAPACITOR VALUES ARE IN MICROFARADS
 2. RESISTOR VALUES ARE IN OHMS
 3. DIODES ARE TYPE IN4003





Figure 7-1. Model 58C Schematic
Diagram (Sheet 1)








Figure 7-2. Model 58C Schematic Diagram (Sheet 2)





















































TTS 58C ADDENDUM 1

1. Replace figure 4-1 with the attached drawing.
2. On the Amplifier and Filter PC Board E95600 Parts List change R109 to 49.9K
3. On the Gating and Driver PC Board E95613 Parts List change R309 to 4.7K and C301 to $56\mu\text{F} \pm 5\%$ part number 150D566X5015R2
4. On the Detector and Regulator PC Board E95614 parts list; change R207 to 137K and C204 to 56pF
5. On the Main Assembly parts list; add : S7, Pushbutton Switch, 81073, 46-101B
6. Replace both sheets of figure 7-1 with the attached schematic diagram.




1. UNLESS OTHERWISE INDICATED:
ALL CAPACITOR VALUES ARE IN MICROFARADS
2. RESISTOR VALUES ARE IN OHMS
3. DIODES ARE TYPE 1N4003





INPUT LEVEL (dBm)
600Ω
-70
-60
-50
-40
-30
-20
-10
-0

S-1 SETTING	LEVEL (dBm)
dBm	
20	-70
30	-60
40	-50
50	-40
60	-30
70	-20
80	-10
90	-0




(dBm)

LEVEL (dBm) WITH 600Ω TERMINATION
AND DISCONNECTED FROM
WEIGHTING NETWORK

- 38
- 38
- 38
- 38
- 38
- 38
- 38
- 38
- 38
- 38

LEVEL (dBm)

- 47.5
- 47.5
- 47.5
- 47.5
- 47.5
- 47.5
- 47.5
- 47.5



AMPLIFIER GAIN
+38 dB

05600 PC-1
& FILTER BOARD


GRD PC 2.8/J
J10.3

LINK

0dB

- R3 64.9 1% -1dB
- R4 57.6 1% -2dB
- R5 52.3 1% -3dB
- R6 46.4 1% -4dB
- R7 41.2 1% -5dB
- R8 36.5 1% -6dB
- R9 31.6 1% -7dB
- R10 28.7 1% -8dB
- R11 26.1 1% -9dB
- R12 21.5 1% -10dB

SI-D1



91431